



Strip back wiring to 10mm by using a wire stripper.



Gently pull back the orange clamps on the connector. Do not force the clamps further than the above image which will damage the connector.



With the clamps in the upright position insert the wires then gently push the clamps down. Gently pull on the wires to make sure that the wires are secure.



**Address:**

**12 Millaroo Drive, HELENSVALE, QLD 4212**

**PH:**

**07 55 000 516**

**FAX:**

**07 55 000 516**

**Email:**

**info@prismaled.com.au**

**Web:**

**www.prismaled.com.au**

